

Network Printer Installation on Windows 7

1. Ensure the printer is connected to machine and is switched on.
2. Click the Start button and select Device and Printers:
3. Click Add printer:
4. Click Add a network, wireless or Bluetooth printer
5. Click The printer that I want isn't listed:
6. Select Add a printer using a TCP/IP address or hostname and click Next:
7. Enter the printer name which will be on or near the printer you want to connect to:
8. The computer will detect the driver model. On the next screen (this can take some time to populate) click Have disk:
9. For Ricoh, select Manufacturer = Ricoh and Printers PCL6 Driver for Universal Print:
10. If the driver was already loaded earlier, you will see a window pop up during installation. (If not, skip to next step.) Select Replace the current driver and click Next:
11. At this point you can either accept the name given to the printer by the Wizard, or give it a unique name of your choice. Then click Next:
12. The Wizard begins loading the drivers for the printer.
13. Select Do not share this printer and click Next:
14. Printer can be Set as the default printer and Test page can be printed to verify the installation was successful.
15. Click Finish.